

GOBI H2 RECOVERY LOOP STEP

Guidelines

When using Load Carriers and Accessories, the user must understand the precautions. The points listed below will assist you in using the rack /carrier system and will encourage safety.


- ♦ For quality fits and safty, use only the recommended rack or accessory. Do not assume an accessory will fit, always check with dealer when obtaining new accessories. Use only approved accessories on load carriers. Using other brands will void your warrenty.
- ♦ Make sure all knobs, bolts, screws, straps, and locks are firmly attached, tightened and locked before every trip. Knobs, bolts, screws, straps, and locks must be periodically inspected for signs of wear, corrosion, and fatigue. Check your load at stops during the trip to insure continued fastening security.
- ♦ Do not use load carriers and accessories for purposes other than those for which they were designed. Do not exceed their carrying capacity.
- ♦ The GOBI recovery loop step has been designed to be mounted to the OEM recovery loops of an H1 and H2 Hummer. When the GOBI Recovery loop assembly is in the open step postion the GOBI Recovery loop step has a maximum load limit of 500lbs.
- ♦ When the GOBI recovery loop step assembly has been placed in the closed step position the recovery loop of the vehicle can be used as original OEM recovery loop equipment. The strength of the recovery loop remains as original OEM equipment. When towing or being towed using the OEM recovery loops be sure the recovery loop steps are in the stowed away position. Do not use the recovery loop steps in the open position when towing or being towed. The recovery loop step support bar may become damaged.
- ♦ With the GOBI recovery loop step in the closed step position, a second perminent small knurled step is accessable by standing on the upper end of the GOBI recovery loop step. This smaller step provides quick, easy access to the vehicle roof area.
- ♦ Consult with your dealer if you have any questions regarding the operations and limits of this product. Review all instructions carefully.

"PATENT PENDING"

GOBI H2 RECOVERY LOOP STEP

Included in kit:

Letter	Description	Quantity
A	GOBI RECOVERY LOOP STEP ASSEMBLY	2
B	H2 RECOVERY LOOP STEP SPACERS <i>(Spacers not required for Hummer model year 04 & earlier)</i>	4
C	M12 x 65 10.9 Recovery Loop Step Bolts M12 Recovery Loop Step Washers <i>(Bolts & washers not required for model year 04 & earlier)</i>	4



GOBI H2 RECOVERY LOOP STEP

Assembly Instructions:

Caution:

If a tire carrier is present on the rear bumper of your vehicle completely remove the tire and the tire carrier swing gate prior to GOBI Step installation.

Note: if your vehicle is an 04 & earlier refer to page 4 for proper instructions.

- 1) Remove OEM bolts "D" and OEM Recovery loops "C" from the rear bumper.
- 2) Pivot the Gobi Recovery Loop Step load bar "E" to its horizontal position as shown in Fig. 2. Place bolts & washers "C" and "D" supplied with kit through Gobi Step "F" then through spacers "B" as shown in Fig. 2. Place the Gobi recovery loop step "F" with attached spacers "B" into the OEM recovery loop "C" as shown in Fig. 2 with knurling "A" in the upwards position.
- 3) Check that the OEM recovery loop "C" is positioned as shown in Fig. 2 page 3 and Fig. 3 page 5 with the curved area of the loop "G" faced down.
- 4) Install the entire OEM recovery loop "C", spacers "B" and Gobi Step "F" assembly onto the rear bumper then tighten all bolts completely. If a tire carrier is present through the tire carrier brackets then into the rear bumper snug bolts only at this time.
- 5) After both recovery loop step assemblies have been installed re-attach the rear tire carrier swing gate to the OEM recovery loop bracket. Place the swing gate into the locked position with out the tire mounted at this time. Completely tighten all bolts then finally mount the spare tire to the swing gate.
- 6) After all bolts have been fully tightened re-position load bar "E" to a vertical position.




Fig. 2

GOBI H2 RECOVERY LOOP STEP

Assembly Instructions:

Caution:

If a tire carrier is present on the rear bumper of your vehicle completely remove the tire and the tire carrier swing gate prior to GOBI Step installation.

Note: Spacers "B", Bolts "D" and washers "C" supplied with kit are not needed. Use OEM bolts to attach the Gobi recovery loop steps.

- 1) Remove bolts "D" and the OEM recovery loop "C" from the bumper and if present the tire carrier.
- 2) Pivot the Gobi Recovery Loop step Load bar "E" to a horizontal position as shown in Fig. 2. Place the GOBI recovery loop step "F" into the OEM recovery loop "C" with knurling "A" in the upwards position as shown in Fig. 2.
- 3) Check that the OEM recovery loop "C" is positioned as shown in Fig. 2 and Fig. 3 page 5 with the curved area of the loop "B" faced down.
- 4) Install the OEM recovery loop bolts "D" through the GOBI Recovery Loop step assembly "F" and through the OEM recovery loop "C" then back into the bumper of the vehicle. If a tire carrier is present then through the tire carrier and into the bumper. Tighten all bolts completely.
- 5) After all bolts "D" are completely tightened pivot the Gobi Recovery Loop Step Load bar "E" in the vertical position as shown in Fig. 4 page 5.




Fig. 2

GOBI H2 RECOVERY LOOP STEP

Instructions for Gobi Recovery Loop Step Use:

- 1) To deploy the Gobi Recovery Loop Step, load bar "E" must be in the vertical position as shown in Fig. 4.
- 2) Raise Recovery Loop "H" to a vertical position then pivot load bar "E" to a horizontal position under the Recovery Loop "H" as shown in Fig. 3. Rest the Recovery Loop "H" on to load bar "E" as shown in Fig. 3. The Gobi Recovery Loop Step is now ready to use. Reverse the process to stow away the Gobi Recovery Loop Step.
- 3) Fig. 4 illustrates the Gobi Recovery Loop Step in the unused or stowed position with only the knurled area "G" used as a quick step.

