

GOBI TOYOTA LAND CRUISER FJ 40 REAR PASSENGER /DRIVER LADDER

INSTALLATION INSTRUCTIONS

(FLIP FOR DRIVER SIDE*)

Guidelines:

When using Load Carriers and Accessories, the user must understand the precautions. The points listed below will assist you in using the rack /carrier system and will encourage safety.

- For quality fits and safety, use only the recommended rack or accessory. Do not assume an accessory will fit, always check with dealer when obtaining new accessories. Use only approved accessories on load carriers. Using other brands will void your warranty.
- Make sure all knobs, bolts, screws, straps, and locks are firmly attached, tightened and locked before every trip. Knobs, bolts, screws, straps, and locks must be periodically inspected for signs of wear, corrosion, and fatigue. Check your load at stops during the trip to insure continued fastening security.
- Check local and state laws governing projection of objects beyond the width of a vehicle. **Be aware of the width and height of your cargo since low clearance branches, bridges, and parking garages can affect the load** All cargo will affect the vehicle's driving behavior. Never drive with any lock, knob, or rack in an open or unlocked position. All long loads such as, but not limited to sailboards, surfboards, kayaks, canoes, and lumber must be tied down front and rear to the bumpers or tow hooks, of the vehicle.
- Remove your rack accessories when they are not in use, before entering car washes, prior to taking in your vehicle for service, and whenever clearance may be an issue.
- All locks must be turned and moved periodically to insure smooth operation. Use graphite or similar dry lubricant to help this. Locks are designed to deter vandalism and theft. Remove valuable gear if your vehicle is unattended for an extended period. Place at least one key in the glove compartment.
- For safety to your vehicle and rack system, obey all posted speed limits and traffic cautions. Adapt your speed to the conditions of the road and the load being carried.
- Do not use load carriers and accessories for purposes other than those for which they were designed. Do not exceed their carrying capacity.
- Consult with your dealer if you have any questions regarding the operations and limits of this product. Review all instructions carefully.


GOBI TOYOTA LAND CRUISER FJ 40 REAR PASSENGER/DRIVER LADDER

INSTALLATION INSTRUCTIONS

(FLIP FOR DRIVER SIDE*)

Included in kit

Letter	Description	Location	Quantity
A	GOBI 06-2011 JEEP JK WRANGLER LADDER	Main box	1
B	HANGER PLATE	Strapped to Ladder	1
C	GOBI LADDER MOUNTING HARDWARE CONTENTS: 4 5/16-18 x 1" SS Button Head Screw 8- 5/16" SS Flat washers 4 5/16" Nylok nuts 1- 3/8-16 x 1" SS Hex Head Bolt 2- 3/8" SS Flat Washer 1- 3/8" Nylok nut 1- 1" Round adhesive backed Brown wear pad	BAG #1 Hardware Box	1



GOBI TOYOTA LAND CRUISER FJ 40 REAR PASSENGER/DRIVER LADDER

INSTALLATION INSTRUCTIONS

(FLIP FOR DRIVER SIDE*)






Fig. 1

As shown above in Fig. 1 place hanger plate (B) supplied with your ladder with the 90 degree angle faced upwards and rearwards onto the two rear support bars (A2) of roof rack (A) and use two 5/16-18 x 1" button head Allen screws, four flat washers and two nylock nuts (2) supplied in Bag #1 of your hardware kit and secure in place. Leave hanger plate (B) snug, do not fully tighten at this time.

GOBI TOYOTA LAND CRUISER FJ 40 REAR PASSENGER/DRIVER LADDERINSTALLATION INSTRUCTIONS
(FLIP FOR DRIVER SIDE*)**Fig. 2**

Place the upper end of ladder (A) onto hanger plate (B) as shown in Fig. 2 and secure in place using two 5/16-18 x 1" Allen screws, four flat washers and two nylock nuts (2) located in Bag #1 of your hardware kit, snug down only at this time. Place the lower ladder support arm (E) on the outside of passenger side rear support (C) ladder flange (C1) as shown in Fig. 2a and insert a 3/8-16 x 1" hex head screw and flat washer (3) located in Bag #1 of your hardware kit through lower ladder arm (E) then through flange (C1) and secure in place with a 3/8" flat washer and nylock nut located in Bag #1, snug down only at this time. Adjust the lower ladder (A) until the rubber bumper (A1) comes in contact or within close proximity to vehicle body then fully tighten screw (3) in place using a 9/16" ratchet or box end wrenches as shown in Fig. 2a. Adjust the upper end of ladder (A) until the ladder is vertically true as seen from the passenger side and rear view of the vehicle then fully tighten all screws on support plate (B) and upper ladder (A). Clean the vehicle body directly behind rubber bumper (A1) with denatured alcohol. Remove the round adhesive backed

Fig. 2a

wear pad from Bag #1 then peel off the protective cover and place directly behind rubber bumper (A1) and press down firmly. The wear pad will prevent abrasion from wearing off paint over time. The pad should be replaced at least once a year.

INSTALLATION COMPLETED