

GOBI BRONCO HARD AND SOFT TOP WIND DEFLECTOR INSTALLATION INSTRUCTIONS

Guidelines

When using Load Carriers and Accessories, the user must understand the precautions. The points listed below will assist you in using the rack /carrier system and will encourage safety.

- For quality fits and safty, use only the recommended rack or accessory. Do not assume an accessory will fit, always check with dealer when obtaining new accessories. Use only approved accessories on load carriers. Using other brands will void your warrenty.
- Make sure all knobs, bolts, screws, straps, and locks are firmly attached, tightened and locked before every trip. Knobs, bolts, screws, straps, and locks must be periodically inspected for signs of wear, corrosion, and fatigue. Check your load at stops during the trip to insure continued fastening security.
- Check local and state laws governing projection of objects beyound the width of a vehicle. **Be aware of the width and height of your cargo since low clearance branches, bridges, and parking garages can affect the load** All cargo will affect the vehicle's driving behavior. Never drive with any lock, know, or rack in an open or unlocked position. All long loads such as, but not limited to sailboards, surfboards, kayaks, canoes, and lumber must be tied down front and rear to the bumpers or tow hooks, of the vehicle.
- Remove your rack accessories when they are not in use, before intering car washes, prior to taking in your vehicle for service, and whenever clearance may be an issue.
- All locks must be turned and moved periodically to insure smooth operation. Use graphite or similar dry lubricant to help this. Locks are designed to deter vandalism and theft. Remove valuable gear if your vehicle is unattended for an extended period. Place at least one key in the glove compartment.
- For safety to your vehicle and rack system, obey all posted speed limits and traffic cautions. Adapt your speed to the conditions of the road and the load being carried.
- Do not use load carriers and accessories for purposes other than those for which they were designed. Do not exceed their carrying capacity.
- Consult with your dealer if you have any questions regarding the operations and limits of this product. Review all instructions carefully.

GOBI BRONCO HARD AND SOFT TOP WIND DEFLECTOR INSTALLATION INSTRUCTIONS



Included in kit

Letter	Description	Location	Quantity
A	GOBI BRONCO HARD AND SOFT TOP WIND DEFLECTOR	Main box	1
B	WIND DEFLECTOR MOUNTING HARDWARE CONTENTS: 3- Black support brackets 4- 1/4-20 x 3/4" Button head SS 2- 5/16-18 x 1" Carriage screws SS 8- 1/4" Black nylon washers 4- 1/4" Nylock nuts 1- 2" x 39" clear wear tape 2- 2" x 2-1/2" clear wear tapes	Bag #1	1




Bag #1

GOBI BRONCO HARD AND SOFT TOP WIND DEFLECTOR INSTALLATION INSTRUCTIONS

Fig. 1**Fig. 2**


As shown in Fig. 1, clean the area above the windshield with denatured alcohol to remove all dirt and debris. As shown in Fig. 1 and Fig. 2, place small pieces of masking tape 1/2" above and across the top edge of the windshield frame just above the windshield shown by red arrows. As shown in Fig. 2, remove a roll of clear wear tape (W) with white backing from Bag #1. Peel off the backing and apply the clear wear tape (W) from the inside edge of accessory cover plate (AC) shown in Fig. 1 to the opposite inside edge of accessory cover plate (AC) shown in Fig. 2 and in line with the top of the masking tape markers. Press down clear wear tape (W) with the palm of your hand and remove any bubbles. Trim off any excess at the end.

Fig. 3**Fig. 4**


As shown in Fig. 3, remove two 2-1/2" x 2" pieces of clear wear tape (W) from Bag # 1, peel off the backing and apply to the top of each accessory cover plate (AC). Figure 4 shows the final clear wear tape application.

CAUTION: USE ANTI-SEIZE LUBRICANT ON ALL SCREWS

GOBI BRONCO HARD AND SOFT TOP WIND DEFLECTOR INSTALLATION INSTRUCTIONS

Fig. 5

As shown in Fig. 5, place center support bracket (CB) to the inside of wind deflector (A). Use one 1/4-20 x 3/4" Button head screw, one black nylon flat washer (S) and set through wind deflector and support bracket (CB). Place one 1/4" black nylon flat washer on the back with one 1/4" nylock nut and snug down in place. Set the wind deflector bracket approximately 1" above the top edge of the wind deflector as shown and fully tighten down using a 5/32" Allen wrench and 7/16" open or closed end wrench.


Fig. 6

As shown in Fig. 6, remove the wind deflector end support brackets (EB) from Bag #1 and mount as shown. Use the longer 5/16-18 x 1" carriage screw supplied in Bag #1 to replace the existing screw (S1). Adjust the bracket so that you have approximately 1" between the center of screw (S1) and end of support bracket as shown and snug down. Leave some play for later adjustment. Apply the same procedure to the opposite side.

GOBI BRONCO HARD AND SOFT TOP WIND DEFLECTOR INSTALLATION INSTRUCTIONS


Fig. 7

As shown in Fig. 7, place the wind deflector (A) center bracket (CB) onto the Gobi light bar mounting plate (P) center slot. Place one 1/4-20 x 3/4" button head screw and one black nylon flat washer (S2) down through support bracket (CB) and into mounting plate (P). Thread onto the underside one 1/4" black nylon washer and 1/4" nylock nut supplied in Bag #1 and snug down in place. Adjust the center bracket (CB) so that the end of the bracket is approximately 1/8" from the edge of mounting plate (P) as shown.


Fig. 8

As shown in Fig. 8, place one 1/4-20 x 3/4" button head screw and one black flat nylon washer (S3) through wind deflector (A) then through support bracket (EB). Thread onto the other side as shown in Fig. 8, one 1/4" black flat nylon washer and one 1/4" nylock nut. Support bracket (EB) will need to be adjusted forward to contact the back of wind deflector (A) to snug down screw (S3). Leave some play for later adjustment.

GOBI BRONCO HARD AND SOFT TOP WIND DEFLECTOR INSTALLATION INSTRUCTIONS

Fig. 9

As shown in Fig. 9, adjust the wind deflector (A) in or out by pushing the end support bracket (EB) in either direction of the red arrow so that the wind deflector has a gap of 1/16" to 1/8" as shown in Fig. 10. Do not allow wind deflector (A) to rest on light bar (B).

Fig. 10

After the adjustment has been made, fully tighten screw (S3) using a 5/32" Allen wrench and 7/16" open or closed end wrench and (S1) using a 1/2" open or closed end wrench. Apply the same procedure to the opposite side.

GOBI BRONCO HARD AND SOFT TOP WIND DEFLECTOR INSTALLATION INSTRUCTIONS



INSTALLATION COMPLETED